ASSEMBLY INSTRUCTIONS . .

MODEL#: RL1063-3

MOTE: Only the technical personnel can be allowto fix and maintain.

IMPORTANTI

Make sure that the power is switch off at the electricity mains supply before commencing work.

FIXING INSTRUCTIONS

 Open perts according to the bag as shown in figure B shows, installed hangs Talwan screw, and should be fixed to the calling in the right place.
 Granud Connection (See picture 1): there are one tapping hole & two

ungives, Wind the supply ground eirs (2) on the green ground screw (15) and then put ir into

tapping hole. Connect the fixture ground wire (3) with supply ground wire (2) by connecting terminal (12). Caution: U() NOT connect ground wire with supply power wire.

3. Connect fixture supply wire with power supply wire. Caution: Remember to distinguish the positive and negative charges. (See picture 2)

4. Fush canony up to the celling and Lock cutterful mux

REPLACEMENT BULB

Do not exceed the maximum wattage. Light bulbs recommended: RL1063-3 -E12 3m800 Max Type B.

CLEANING CARE

Clean with a soft dry cloth.

SAFETY INFORMATION

1. Lamp used must in rated voltage, and do not touch the built with bare hands. Always switch off the electricity supply and allow to cool for 10 minutes before changing the light builts.

before changing the light bulbs.

2. If the external cables have been demaged, Pls change or supair by manufacturer or service agency or professional electrician, In order to evold the danger.



